

DURABLE CAMERAS

What if you could take photos underwater, on a sandy beach, or from a ski slope in freezing conditions without worrying about the well being of your camera? You can with one of several durable cameras designed to withstand water, shocks, sand, and even freezing temperatures! One of these three cameras may be the perfect choice for your next vacation.

<p><i>Camera</i></p>	<p>Kodak EasyShare Sport store.kodak.com</p> 	<p>Fujifilm FinePix XP30 fujifilm.com</p> 	<p>Olympus Stylus Tough-810 olympusamerica.com</p> 
Retail Price	\$79.95	\$239.95	\$379.99
Megapixels	12	14.2	14
Waterproof	Up to 10 feet underwater	Up to 16.4 feet underwater	Up to 33 feet underwater
Shockproof	No	Survives drops up to 4.9 feet	Survives drops up to 6.6 feet
Crushproof	No	No	Up to 220 pounds of pressure
Freezeproof	No	Min 14°F	Min 14°F
ISO	Auto: 80-1250	Auto: 100-3200	Auto, High Auto: 80-1600 (equivalent)
ShutterSpeed	Auto: 1/4-1/1400 sec. Long time exposure: 1/2 -8 sec..	Auto: 1/4-1/2000 sec. All other modes: 4-1/2000 sec..	1/2000 -1/4 sec. Up to 4 sec. in Night Scene mode
Zoom	5x advanced digital	5x optical zoom	5x digital zoom
HD Video	Motion JPEG, AVI 2.0 with sound	AVI Motion JPEG with sound	MPEG-4 Movie with sound
Other	With Kodak's Share button you can tag pictures directly from your camera for e-mailing to friends or uploading online.	With one press of the shutter, Motion Panorama mode automatically takes and stitches together three consecutive shots and saves the resulting panoramic to the memory card.	In-camera Panorama captures three images and stitches them together creating a panoramic picture by pressing the shutter button and slowly panning across a scene.

Note: All cameras listed are point-and-shoot.

Tip: Some cameras offer a casing that you can purchase separately to make your camera waterproof. Check with your local camera shop or online to see if one is available for your camera.